

### 2.3.4 Summary to: Conductors - Special Applications

Thermionic emission provides electron beams.  
The electron beam current (density) is given by the *Richardson equation*:

●  $A_{\text{theo}} = 120 \text{ A} \cdot \text{cm}^{-2} \cdot \text{K}^{-2}$  for free electron gas model  
 $A_{\text{exp}} \approx (20 - 160) \text{ A} \cdot \text{cm}^{-2} \cdot \text{K}^{-2}$

●  $E_A$  = work function  $\approx (2 - >6) \text{ eV}$

● Materials of choice: **W**, **LaB<sub>6</sub>** single crystal

High field effects (tunneling, barrier lowering) allow large currents at low  $T$  from small (nm) size emitter

$$j = A \cdot T^2 \cdot \exp - \frac{E_A}{kT}$$

Needs **UHV**!

There are several thermoelectric effects for metal junctions; always encountered in non-equilibrium.

● *Seebeck effect*:  
Thermovoltage develops if a metal A-metal B junction is at a temperature different from the "rest", i.e. if there is a temperature gradient

Essential for measuring (high) temperatures with a "thermoelement"  
Future use for efficient conversion of heat to electricity ???

#### Questionnaire

All Multiple Choice questions to 2.3