





## 6.1.4 Summary to: 6.1 Materials and Processes for Silicon Technology


- Making "metallurgical" (= "dirty") **Si<sub>met</sub>** is easy: ⇒
  - A large scale **Si<sub>met</sub>** production (> **1 Mio tons/a**) exists for metallurgical ("alloying") and chemical ("silicones") uses
- A small amount of **Si<sub>met</sub>** (some **20.000 to/a**) is purified (factor **10<sup>9</sup>** or so) to "semiconductor grade **Si**" ⇒
  - Produce high-purity trichlorosilane (**SiHCl<sub>3</sub>**) gas in a reactor and distill.
  - Use **SiHCl<sub>3</sub>** and **H<sub>2</sub>** to deposit **Si** on some **Si** core by a **CVD** process
- The final result is ultra-high purity (and expensive) **poly Si** (already doped if so desired)



- Growing a "perfect" single crystal from this **poly-Si** is not easy - but possible.
  - The major crystal growth method is the **CZ** (= Czochalski) method: "Pull" the crystal from a crucible full of molten **Si**. ⇒
  - Some (usually < **300 mm** diameter) crystals are grown by the **FZ** (= float zone) method. Somewhat better perfection, but more expensive than **CZ**.
- Major problem: Impurity segregation = general tendency for most impurities (including doping atoms) to remain (= enrich) in the melt.
  - Segregation coefficient =  $c_{\text{cryst}}/c_{\text{melt}}$  at interface, often << **1** and dependent on parameters like growth speed (usually a few **mm/min**).
  - + Crystal is purer than melt.
    - It is practically impossible to grow a crystal with a uniform impurity (including dopant!) concentration along its length.



- Produce wafers by cutting, grinding and polishing
  - Extreme precision for a mass product is needed.
  - "Flats" or "notches" (for wafers > **200 mm**) identify the crystallographic orientation and the doping type.
  - Beware! Flats are often custom specific and different from the norm. ⇒



### Questionnaire

Multiple Choice questions to all of 6.1