

# Commercial Wafer Specifications

Here are the specification for Si wafers from one of the worlds top companies, **Wacker Siltronic**, as they appear in the Internet in Nov. 2000.

- Notice:** Concentrations here are in  $\text{cm}^3$ . The conversion to parts per .. is simple:  
The atomic density of Si is  $4.96 \cdot 10^{22} \text{ cm}^{-3}$  or about  $5 \cdot 10^{22} \text{ cm}^{-3}$ .  
**1 ppm thus corresponds to  $5 \cdot 10^{16} \text{ cm}^{-3}$ .**
- The lowest concentration given in the table (look for it) is  $5 \cdot 10^{10} \text{ cm}^{-3}$ ; it corresponds to **1 ppt** or  $10^{-12}$ .
- Surface concentrations **[S]** (given in  $\text{cm}^{-2}$ ) are converted to volume concentrations **[V]** by  
**[S] = [V] / a** with **a** = lattice constant (= **0,5431 nm**) or, more precise for single crystals, distance between the crystallographic planes. With **a**  $\approx$  **0,5 nm** =  $5 \cdot 10^{-8} \text{ cm}$ , we have  
**[V] =  $5 \cdot 10^{16} \text{ cm}^{-3}$  = 1 ppm** corresponds to **S =  $10^8 \text{ cm}^{-2}$ .**
- Many specifications relate to the "flatness" of the wafers and the perfection of the surface; the abbreviations used are  
**LLS** (sometimes also abbreviated **LPDs**): **Localized Light Scattering Defect**; this relates to a detection method of **sub- $\mu\text{m}$**  size surface imperfections (resulting from bulk microdefects)  
**SFQR**: **Site flatness quality requirements** (??): Definitely a measure of flatness in a region comparable to the size of a single chip  
*(The rest: Who knows?)*
- Here is a link with precise defininitioons of geometricla parameters:  
[http://www.freiberger.com/english/products/geom\\_parameters.php](http://www.freiberger.com/english/products/geom_parameters.php)

## Polished & Epitaxial Wafers for IC Applications

Crystal / Bulk			300mm	200mm	150mm	125mm	100mm
Growth Technique *)			CZ	CZ	CZ	CZ	CZ
Orientation			1-0-0	1-0-0	1-0-0 / 1-1-1	1-0-0 / 1-1-1	1-0-0 / 1-1-1
Orientation Tolerance		degree	$\pm 0.2$	$\pm 0.2$	$\pm 0.5$	$\pm 0.5$	$\pm 0.5$
Off Orientation		degree	0	0 - 4	0 - 4	0 - 4	0 - 4
Dopant			Boron / Phosphorus	Boron / Phosphorus	Boron / Phosphorus	Boron / Phosphorus	Boron / Phosphorus
Resistivity Target Range	pol prime - Boron	Ohmcm	0.5 - 50	0.5 - 50	0.5 - 50	0.5 - 50	0.5 - 50
	pol prime - Phosphorous	Ohmcm	1.0 - 50	1.0 - 50	1.0 - 50	1.0 - 50	1.0 - 50
	epi substrate - Boron	Ohmcm	0.006 - 50	0.006 - 50	0.006 - 50	0.006 - 50	0.006 - 50
Radial Resistivity Variation	Boron typical	1-0-0 / 1-1-1	%	< 10	< 5	< 5 / < 6	< 6 / < 10
	Phosph. typical	1-0-0 / 1-1-1	%	< 15	< 12 / < 25	< 12 / < 25	< 15 / < 25
Oxygen Target Range $\pm$ Tol.	pol prime - Boron	1-0-0		$4.8 - 7.8 \times 10^{11} \pm 0.5$	$5 - 7.8 \times 10^{11} \pm 0.5$	$5.8 - 8.9 \times 10^{11} (\pm 0.6 - 0.8)$	$5.8 - 8.9 \times 10^{11} (\pm 0.5 - 1.0)$
		1-1-1	at $\text{cm}^{-3}$	NA	NA	$5.8 - 8.9 \times 10^{11} (\pm 0.7 - 1.0)$	$5.8 - 8.9 \times 10^{11} (\pm 0.8 - 1.2)$
	pol prime - Phosph.	1-0-0	ASTM F121-83	$4.8 - 7.8 \times 10^{11} \pm 0.5$	$6 - 7.5 \times 10^{11} \pm 0.5$	$5.8 - 8.9 \times 10^{11} (\pm 0.6 - 0.8)$	$5.8 - 8.9 \times 10^{11} (\pm 0.5 - 1.0)$
		1-1-1		NA	NA	$5.8 - 8.9 \times 10^{11} (\pm 0.7 - 1.0)$	$5.8 - 8.9 \times 10^{11} (\pm 0.8 - 1.2)$
Radial Oxygen Variation	typical	1-1-1	%	< 10	< 5	< 6	< 5 - 10
Bulk Metal Concentration	Fe	at $\text{cm}^{-3}$	$\leq 5.0 \times 10^{10}$	$\leq 5.0 \times 10^{10}$	$\leq 1.0 \times 10^{11}$	$\leq 1.0 \times 10^{11}$	$\leq 1.0 \times 10^{11}$
Bulk Carbon Concentration	measured on wafer	at $\text{cm}^{-3}$	$\leq 2.0 \times 10^{11}$	$\leq 2.0 \times 10^{11}$	$\leq 2.0 \times 10^{11}$	$\leq 2.5 \times 10^{11}$	$\leq 2.5 \times 10^{11}$

  

Polished Wafers / Substrates			300mm	200mm	150mm	125mm	100mm
Surface Metals	Cu / Cr / Fe / Ni	at $\text{cm}^{-2}$	$\leq 1.0 \times 10^{11}$	$\leq 2.5 \times 10^{11}$	$\leq 5.0 \times 10^{11}$	$\leq 5.0 \times 10^{11}$	$\leq 5.0 \times 10^{11}$
	Al / Zn / K / Na / Ca	at $\text{cm}^{-2}$	$\leq 5.0 \times 10^{11}$	$\leq 1.0 \times 10^{11}$	$\leq 2.0 \times 10^{11}$	$\leq 2.0 \times 10^{11}$	$\leq 2.0 \times 10^{11}$
LLSs (Frontside *)	size	$\mu\text{m}$	> 0.2	> 0.16	> 0.12	> 0.3	> 0.12
	pol prime	# per wafer	< 30	< 40-300	< 200-10 <sup>1</sup>	< 15-35	< 20-120
	UltraFlat (150 mm)	# per wafer	NA	NA	NA	NA	NA
	monitor	# per wafer	< 30	< 60	< 100	< 15	< 20-65
Diameter Tolerance		mm	$\pm 0.2$	$\pm 0.2$	$\pm 0.2$	$\pm 0.2$	$\pm 0.2$
Warp	polished - without layer	$\mu\text{m}$	< 50	< 20	< 30	< 30	< 30
Wafer / Substrate Thickness	Standards	$\mu\text{m}$	775	725	375 / 525 / 625 / 675	375 / 525 / 625	300 / 375 / 525
Thickness Tolerance		$\mu\text{m}$	$\pm 25$	$\pm 15$	$\pm 15$	$\pm 15$	$\pm 15$
GBIR = TTV (Std   UltraFlat *)		$\mu\text{m}$	< 4	< 3.5	< 5.0	< 2.5	< 5.0
GFLR = TIR (Std   UltraFlat *)		$\mu\text{m}$	NA	< 2.0	< 2.0	< 1.2	< 2.0
Local Flatness *)	SFQR / STIRmax, s.b.f.	$\mu\text{m}$	< 0.25	< 0.25	< 0.5	< 0.3	NA
	SFQD / SFPD, s.b.f.	$\mu\text{m}$	< 0.18	< 0.18	< 0.3	< 0.2	NA
	SBIR / STIRmax, b.r.	$\mu\text{m}$	NA	< 0.7	< 1.0	< 0.6	< 1.0
Standard Site Size		mm <sup>2</sup>	25 x 25	25 x 25	15 x 15	15 x 15	15 x 15